



## 8cm Camcorder Compatibility Reference Guide

### SONY CAMCORDERS

| MODEL NAME | SUPPORT FORMAT      |
|------------|---------------------|
| DCR-DVDI00 | DVD-R/-RW           |
| DCR-DVDI01 | DVD-R/-RW           |
| DCR-DVDI03 | DVD-R/-RW/+RW       |
| DCR-DVDI05 | DVD-R/-RW/+RW       |
| DCR-DVDI08 | DVD-R/-RW/+RW/+R DL |
| DCR-DVD200 | DVD-R/-RW           |
| DCR-DVD201 | DVD-R/-RW           |
| DCR-DVD203 | DVD-R/-RW/+RW       |
| DCR-DVD205 | DVD-R/-RW/+RW       |
| DCR-DVD300 | DVD-R/-RW           |
| DCR-DVD301 | DVD-R/-RW           |
| DCR-DVD305 | DVD-R/-RW/+RW       |
| DCR-DVD308 | DVD-R/-RW/+RW/+R DL |
| DCR-DVD403 | DVD-R/-RW/+RW       |
| DCR-DVD405 | DVD-R/-RW/+RW       |
| DCR-DVD408 | DVD-R/-RW/+RW/+R DL |
| DCR-DVD505 | DVD-R/-RW/+RW       |
| DCR-DVD508 | DVD-R/-RW/+RW/+R DL |
| DCR-DVD7   | DVD-R/-RW/+RW       |
| DCR-DVD803 | DVD-R/-RW/+RW       |
| DCR-DVD92  | DVD-R/-RW/+RW       |
| HDR-UX1    | DVD-R/-RW/+RW/+R DL |
| HDR-UX5    | DVD-R/-RW/+RW/+R DL |
| HDR-UX7    | DVD-R/-RW/+RW/+R DL |

### CANON CAMCORDER

| MODEL NAME | SUPPORT FORMAT |
|------------|----------------|
| DC10       | DVD-R/-RW      |
| DC100      | DVD-R/-RW      |
| DC20       | DVD-R/-RW      |

### HITACHI CAMCORDERS

| MODEL NAME | SUPPORT FORMAT    |
|------------|-------------------|
| DZBX35A    | DVD-R/-RW/+RW/RAM |
| DZGX20A    | DVD-R/RAM         |
| DZGX20MA   | DVD-R/-RW/RAM     |
| DZGX20MA   | DVD-R/-RW/RAM     |
| DZGX3100A  | DVD-R/-RW/+RW/RAM |
| DZGX3200A  | DVD-R/-RW/+RW/RAM |
| DZGX3300A  | DVD-R/-RW/+RW/RAM |
| DZGX5020A  | DVD-R/-RW/+RW/RAM |
| DZGX5080A  | DVD-R/-RW/+RW/RAM |
| DZHS500A   | DVD-R/-RW/+RW/RAM |
| DZHS300A   | DVD-R/-RW/+RW/RAM |
| DZMV350A   | DVD-R/RAM*        |
| DZMV380A   | DVD-R/RAM*        |
| DZMV550A   | DVD-R/RAM*        |
| DZMV580A   | DVD-R/RAM*        |
| DZMV730A   | DVD-R/RAM         |
| DZMV750MA  | DVD-R/-RW/RAM     |
| DZMV780A   | DVD-R/RAM         |
| DZMV780MA  | DVD-R/-RW/RAM     |

### SAMSUNG CAMCORDER

| MODEL NAME | SUPPORT FORMAT      |
|------------|---------------------|
| SC-DCI63   | DVD-R/-RW/+RW/+R DL |
| SC-DCI64   | DVD-R/-RW/+RW/+R DL |
| SC-DCI65   | DVD-R/-RW/+RW/+R DL |
| SC-DC563   | DVD-R/-RW/+RW/+R DL |
| SC-DC564   | DVD-R/-RW/+RW/+R DL |
| SC-DC565   | DVD-R/-RW/+RW/+R DL |
| SC-DC575   | DVD-R/-RW/+RW/+R DL |
| SC-DCI73U  | DVD-R/-RW/+RW/+R DL |



## 8cm Camcorder Compatibility Reference Guide

### CANON CAMCORDER (Continued)

| MODEL NAME | SUPPORT FORMAT  |
|------------|-----------------|
| DC210      | DVD-R/-RW/-R DL |
| DC22       | DVD-R/-RW/-R DL |
| DC220      | DVD-R/-RW/-R DL |
| DC230      | DVD-R/-RW/-R DL |
| DC40       | DVD-R/-RW       |
| DC50       | DVD-R/-RW/-R DL |

### PANASONIC CAMCORDERS

| MODEL NAME | SUPPORT FORMAT      |
|------------|---------------------|
| HDC-DXI    | DVD-R/-RW/RAM/-R DL |
| VDR-DI00   | DVD-R/-RW/RAM       |
| VDR-DI05   | DVD-R/-RW/RAM       |
| VDR-D200   | DVD-R/-RW/RAM       |
| VDR-D210   | DVD-R/-RW/RAM/-R DL |
| VDR-D220   | DVD-R/-RW/RAM/-R DL |
| VDR-D230   | DVD-R/-RW/RAM/-R DL |
| VDR-D250   | DVD-R/-RW/RAM       |
| VDR-D300   | DVD-R/-RW/RAM       |
| VDR-D310   | DVD-R/-RW/RAM/-R DL |
| VDR-M30    | DVD-R/RAM*          |
| VDR-M50    | DVD-R/RAM*          |
| VDR-M53    | DVD-R/RAM           |
| VDR-M55    | DVD-R/RAM           |
| VDR-M70    | DVD-R/RAM*          |
| VDR-M75    | DVD-R/RAM           |
| VDR-M95    | DVD-R/RAM           |

\*The round DVD holder is required

Supported formats are subject to change by camcorder manufacturers at any time. Confirm the formats supported by your camcorder to determine its DVD media requirements before your media purchase.